

2011 Cadillac Truck SRX FWD V6-3.0L

Vehicle > Body and Frame > Relays and Modules - Body and Frame > Power Trunk / Liftgate Control Module > Testing and Inspection > Programming and Relearning

LIFTGATE CONTROL MODULE PROGRAMMING AND SETUP

Liftgate Control Module Programming and Setup

Note: To ensure proper programming of the liftgate, the liftgate assembly must be at room temperature during calibration.

Note: DTC B1019 00 will set automatically as an indicator that the system is in learn mode and not as a fault indicator. Once the travel limits are learned by the liftgate module, the liftgate module will exit calibration mode and DTC B1019 00 become a history code.

Conditions

Use this procedure after replacing, repairing, or disassembling any portion of the power liftgate assembly.

1. Connect the scan tool to the vehicle.
2. Select Module Diagnosis.
3. Select Liftgate Control Module.
4. Select Liftgate Maximum Open Position Learn.