

## 2008 Audi A3 (8PA) L4-2.0L Turbo (CBFA)

## Vehicle &gt; Power and Ground Distribution &gt; Fuse &gt; Application and ID &gt; Components

No.	Equipment	Amps	No.	Equipment	Amps
F1	Anti-lock brake system (ABS) pump	30	F31	Front windshield wiper system	30
F2	Anti-lock brake system (ABS) valves	30	F32	Not used	--
F3	Not used	--	F33	Not used	--
F4	Battery voltage	5	F34	Not used	--
F5	Horn	15	F35	Not used	--
F6	Volume control valve/fuel pump	15	F36	Not used	--
F7	Not used	--	F37	Not used	--
F8	Not used	--	F38	Engine components	10
F9	Engine components	10	F39	Clutch pedal switch, brake light switch	5
F10	Fuel tank control, mass air flow sensor	10	F40	Ignition coils	20
F11	Oxygen sensors, in front of catalytic converter	10	F41	Not used	--
F12	Oxygen sensors, behind catalytic converter	10	F42	Power supply engine relay	5
F13	Automatic transmission	15	F43	Ignition coils	30
F14	Not used	--	F44	Not used	--
F15	Water return-flow pump	10	F45	Not used	--
F16	Steering wheel electronics	5	F46	Not used	--
F17	Instrument cluster module	5	F47	Left-side lighting (electric system control unit)	30
F18	Audio amplifier	30	F48	Right-side lighting (electrical system control unit)	30
F19	Navigation system, radio system	15/25	F49	Power supply relay terminal 15	40
F20	Navigation system, digital radio, cell phone, TV equipment	5	F50	Not used	--
F21	Not used	--	F51	Secondary air pump	40
F22	Not used	--	F52	Power supply relay terminal 75	50
F23	Engine control module, main relay	10	F53	Fuse assignment in the left-side instrument panel (special equipment)	50
F24	Control module for CAN data transfer (gateway)	5	F54	Not used	--
F25	Not used	--			
F26	Not used	--			
F27	Not used	--			
F28	Engine control module	15			
F29	Engine relays, engine components	5			
F30	Not used	--			